

## ASSEMBLY DRAWING

MODEL #:8CJGF

### LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. LAY FIBERGLASS TOP UPSIDE DOWN ON A NON-ABRASIVE SURFACE. SET A TABLE LEG ON THE TABLE TOP. LINE UP THE TOP ANGLE HOLES WITH THE PREDRILLED PILOT HOLES. ATTACH WITH  $\frac{3}{8}$ " x 2" LAG SCREWS. NOTE: YOU MAY NEED TO TAP THE SCREWS WITH A HAMMER IN ORDER TO START THE SCREWS INTO THE PILOT HOLES.
2. CONNECT THE BRACES TO THE PREDRILLED CENTER HOLE(S) AND THE LEG SPACER.
3. TURN TABLE OVER AND ATTACH THE SEAT PLANKS.

