

ASSEMBLY DRAWING

MODEL #:6BGA

LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

1. BOLT THE LEGS TOGETHER AS SHOWN WITH THE BRACE BETWEEN THE LEGS, (BENT END AWAY FROM THE LEG) AND THE TOP ANGLE FACING THE SAME WAY.
2. LAY THREE PLANKS ON THE GROUND CLOSE TOGETHER AND PUT HOLD DOWN CLIPS INSIDE PLANK.
3. PLACE A SET OF LEGS UPSIDE DOWN. PUT BOLTS THROUGH HOLD DOWN CLIP AND FINGER TIGHTEN W/ FLANGE NUTS. REPEAT FOR OTHER END OF THE TABLE. BE SURE TOP ANGLES FACE TOWARD THE CENTER. LEGS SHOULD BE EQUAL DISTANCES FROM EACH END.
4. ATTACH THE SEAT PLANKS WHILE THE TABLE IS UPSIDE DOWN.
5. ATTACH CENTER CLEAT WITH HOLD DOWN CLIPS.
6. CONNECT THE BRACES TO THE CENTER CLEAT.
7. ATTACH END CAPS AS SHOWN BELOW.

