## LEAVE ALL BOLTS LOOSE UNTIL ALL ARE IN PLACE.

- 1. BOLT THE LEGS TOGETHER AS SHOWN WITH THE BRACE BETWEEN THE LEGS, AND THE TOP ANGLE AND SEAT ANGLES FACING THE SAME WAY. NOTICE THERE IS A LEFT AND RIGHT SEAT ANGLE. ATTACH APPROPRIATELY. THE BENT END OF BRACE POINTS AWAY FROM THE LEG.
- LAY THREE PLANKS ON THE GROUND CLOSE TOGETHER PUT HOLD DOWN CLIPS INSIDE PLANK.
- 3. PLACE A SET OF LEGS UPSIDE DOWN. PUT BOLTS THROUGH HOLD DOWN CLIP AND TIGHTEN W/ FLANGE NUTS. REPEAT FOR THE OTHER END OF THE TABLE. BE SURE THE TOP ANGLES FACE TOWARD THE CENTER.

